




362406
362407
Overheat
protection




362404
Overheat
protection




362405
Overheat
protection




362402
Aftercooling
thermostat




362408
Stove lid
thermostat




362401
Aftercooling
thermostat




362413
Aftercooling
thermostat



362409
Aftercooling
thermostat



362403
Copper holder



364006
Insul. plate for
thermostat

362402
Aftercooling
thermostat