

## Diesel heater, Nautic 30D

Art. No.	version	Description	Unit
<b>Electronics</b>			
361037	→ 90630	Control unit , T4 / Wallas 30D <i>v 1.31</i>	Pcs
361047		Control unit 30D <i>v 1.35</i>	Pcs
361026	90631 →	Control unit, 30D T4 / Std <i>v 1.31</i>	Pcs
361048		Control unit, motor filter 30D	Pcs
362102		Fuse 5 A / 10 Pcs	Set
362104		Fuse 15 A / 10 Pcs	Set
362101		Fuse 4 A / 10 Pcs	Set
363503		Info Control Panel / Service	Pcs
362406		Overheat thermostat 120° C <i>Auto-reset</i>	Pcs
362302	→ 23221	Power connector, female	Pcs
362304	23222 →	Power connector, female	Pcs
362303	→ 23221	Power connector, male	Pcs
362305	23222 →	Power connector, male	Pcs
362306	→ 23221	Power connector, support plate	Pcs
362307	23222 →	Power connector, support plate	Pcs
<b>Wire sets</b>			
363015		Cable, For info control panel, 10 m	Pcs
363014		Cable, for info control panel, 6 m	Pcs
363016		Cable, 6m for control panel	Pcs
363012		Glow plug wire set 30D/95D	Pcs
363048		Overheating thermostat with wire set	Pcs
363401	→ 23221	Power cable with conn. <i>4 m</i>	Pcs
363404	23222 →	Power cable with conn.	Pcs
363050		Wire set for fuel pump	Pcs
<b>Combustion blower</b>			
365307		Motor/rotor/plate	Pcs
<b>Burner</b>			
364023		Bottom mat, Ø 85 mm	Pcs
369008		Burner cylinder complete <i>Complete, without T4, Glow plug, Fuel nozzle</i>	Pcs
363506		Filters Testo 305-2 / 10 pcs	Pcs
364010		Gasket for glow plug / 5 Pcs <i>D 21/13 x 6,0 mm</i>	Set
364015		Gasket for T4 thermo element <i>D24/8x5 mm</i>	Pcs
362502		Glow plug 11 V	Pcs
369011		Outer cylinder for burner	Pcs
369007		Radiation element	Pcs
363505		Soot Pump	Pcs
362601		Thermo element + gasket	Pcs
<b>Fuel systems</b>			
367112		Connector nut, 5 mm / 5 Pcs	Set
367106		Extension connector, 5 mm	Pcs
367403		Fuel filter complete	Pcs
367402		Fuel filter head	Pcs
367401		Fuel filter,external,stand. / 30015	Pcs
367211		Fuel hose, Ø 5 / 2 mm	M

367306	Fuel pipe (Cu)	Pcs
367501	Fuel pump FC 1 <i>Pump FC 1 is delivered with assembly plate (601967)</i>	Pcs
367206	Fuel tank fitting	Pcs
364001	Fuel tank gasket <i>Ø 36,5/27,5 x 3 mm</i>	Pcs
367103	Holder bushing 2 x 10 x 0,3 mm / 10 Pcs	Set
367115	L-Connector clip	Pcs
367108	L-connector, 5 mm	Pcs
363507	Measure glass 100 ml, glass	Pcs
367119	Mounting set for fuel hose <i>holder bushing Ø2mm + olive ring Ø5mm + connector nut Ø5mm</i>	Pcs
367110	Olive ring, 5 mm / 10 Pcs	Set
367001	Shield spiral	Pcs

#### Main blower

365406	Complete main blower 30D	Pcs
365107	Motor, axle 3,2 mm	Pcs
365202	Rotor <i>76 x 57 x 3,2 mm</i>	Pcs

#### Structure parts

368031	Bracket for pcb 30D	Pcs
369017	Burner chamber bottom 30D	Pcs
364017	Gasket, 87/61x4 mm (2460)	Pcs
368509	Heat exchanger 30D	Pcs
364025	Rubber gasket 45/15x3 (30011)	Pcs
364005	Rubber gasket, 31/16x3 mm (2460)	Pcs
364003	Rubber gasket, 58/31x3 mm (2460)	Pcs

#### Accessories

2462	Adapter for exhaust	Pcs
30010	Cable 5 m, solenoid valve	Pcs
2025	Cap for fuel tank <i>5L, 10L, 30L</i>	Pcs
4414	Duct adapter, Ø 60/75 mm	Pcs
3414	Duct adapter, Ø 75/90 mm	Pcs
602309	Electrical insulation set	Pcs
2069	Exhaust extension kit	Pcs
1028	Exhaust pipe, Ø 28 mm, Stainless	M
2448	Exhaust pipe, Ø 28/45 mm, Inox	M
2045	Exhaust pipe, Ø 45 mm, Inox	M
30014	Fuel filter set	Pcs
30015	Fuel filter set, standard	Pcs
300693	Fuel hose assy, with filter	Pcs
36315	Fuel pipe (Cu), 4 m	Pcs
3001	Fuel tank fitting, complete / Diesel <i>Incl. 30011 and 30012</i>	Set
2027	Fuel tank, 10 L	Pcs
4030	Fuel tank, 30 L	Pcs
300692	Fuel tube, Cu, 4 m	Pcs
2467	Hull lead-through	Pcs
3005	Info control panel <i>The unique Wallas control system, based on an info display, includes the following functions: Timer: The heater can be set to start up to 31 days in advance, and the running time can be set from 0-24 hours. Cabin temperature indicator and thermostat control: The thermostat is located inside the Info Control Panel. The thermostat's reaction to temperature changes can be adjusted. Manual power adjustment is also possible. Versatile operation details: The info display clearly indicates power consumption (A), fuel consumption (l/h), burner temperature, operating hours, battery voltage and status. It also indicates the need for scheduled maintenance and any disorders such as: flame out, damaged glow, low voltage, overheating and faults in fan functions.</i>	Pcs
3412	Insulation hose, Ø 75 mm <i>I.D.</i>	M
2461	Insulation kit	Pcs

4133	Mounting kit of the plug	Pcs
2422	Room thermostat	Pcs
2460	Sealable deck lead-through	Pcs
30012	Solenoid valve <i>12V/0,5 A</i>	Pcs
30016	Solid Fuel Filter	Pcs
10856	Spiral, (2460)	Pcs
3004	Standard control panel	Pcs
3468	Standard lead-through, combination	Pcs
367215	Tank feed through, diesel	Pcs
30011	Tank fitting / Diesel <i>RST, 1 m</i>	Pcs
3413	Warm air 3-Way divider, Ø 75 mm	Pcs
3410	Warm air hose, Ø 75 mm	M
3411	Warm air ventilation, Ø 75 mm	Pcs